


HPRT

Handheld Barcode Scanner

N130BT



User Manual

Xiamen Hanin Electronic Technology Co., Ltd.

ADD: 5F, 8# Building, Aide Airport Industrial Park, Huli District, Xiamen, China

WEB: www.hprt.com

Disclaimer

Change Record

Chapter 1 Introduction	1
Chapter 2 Communication Interface	7
Chapter 3 Scanning Mode.....	15
Chapter 4 Illumination and Aiming	18
Chapter 5 Symbologies.....	19

Chapter 6 Troubleshooting	38
Chapter 7 Scanner Settings.....	39

)



()

Appendix I Barcode Enabling Settings	48
Appendix II Data code prefix and suffix.....	50
Appendix III ASCII Code Table	57

Chapter 1 Introduction

i € /

Appearance



① Sound Hole

② Scan Window


③ Scan Button

④ Indicator

⑤ Type-C

⑥ Shutdown Hole

Dimension




Interface

BT connection



Type-c connection



Power on, Power off and Restart

■ Start up:

■ Shut down:

■ Restart:

Maintenance

✧

✧

✧

✧

✧

✧

Barcode Read

▲Note: For the same batch of barcodes, the scanner keeps a very high success ratio in certain distance which is regarded as the optimal scanning distance.

Use the Setting Barcode

Restore Factory Defaults



Chapter 2 Communication Interface


USB Interface




HID Virtual Keyboard




USB International Keyboard Setting











USB Virtual Serial Port



Bluetooth Interface



Set scanner switch time (Bluetooth mode only)



Bluetooth pop-up iPhone keyboard settings (Bluetooth mode only)



VID & PID Table

Device Name	Interface Type	PID (Hex)	PID (Decimal)

Chapter 3 Scanning Mode

Manual Mode



Sense Mode



Sensitivity



✧ Single Reading Time

Continuous Mode



✧ Single Reading Time Limit

Command Programming

Chapter 4 Illumination and Aiming

Aiming



Illumination



Read success prompt tone



Chapter 5 Symbologies

1D Barcode Setting

ENA-8

Enable/Disable EAN-8



Enable/Disable 2/5-bit Add-On code



Convert EAN-8 to EAN-13



ENA-13

Enable/Disable EAN-13



Enable/Disable 2/5-bit Add-On code



UPC-E

Enable/Disable UPC-E



Transmit check character



Enable/Disable 2/5-bit Add-On code




Convert UPC-E to UPC-A



System character transmit



UPC-E1




Enable/Disable 2/5 Add-On code



UPC-A


Enable/Disable UPC-A



Transmit check character



Enable/Disable 2/5-bit Add-On code



Transfer system character



Code 39

Enable/Disable Code 39



Check character verification and transmit



Enable/Disable code 39 Full ASCII



Convert Code 39 to Code32



Code 32 prefix



Code 93

Enable/Disable code 93





Code 11

Enable/Disable code 11



Check Setting



Transmit check character



Code 128

Enable/Disable code 128



Note: if this barcode is set to disable, the scanner will not be able to scan and switch the corresponding function settings.

Code 128 <FNC4>



Codabar

Enable/Disable Codabar



Start and stop characters



MSI

Enable/Disable MSI



Check Setting



Check bit algorithm



Transmit check character



Interleaved 2 of 5


Enable/Disable Interleaved 2 of 5



Check and transmit character



Convert I 2 of 5 to EAN-13



Matrix 2 of 5

Enable/Disable Matrix 2 of 5



Check and transmit character



Industrial 2 of 5

Enable/Disable Industrial 2 of 5



Standard 25

Enable/Disable Standard 25




ISSN



ISBN



Data bit setting



ISBT 128

Enable/Disable ISBT 128



GS1 128

Enable/Disable GS1 128



Gs1-128 emulation mode for UCC/EAN composite code



GS1 DataBar

Enable/Disable GS1 DataBar



Convert GS1 DataBar to UPC/ENA



GS1 DataBar Limited

Enable/Disable GS1 DataBar Limited



GS1 DataBar Expanded

Enable/Disable GS1 DataBar Expanded



1D Barcode Inverse



1D Barcode Anti-color



2D Barcode Setting

PDF417

Enable/Disable PDF417



Data Matrix

Anti-color



Enable/Disable Data Matrix



Mirror Images



Inverse



QR

Enable/Disable QR



Enable/Disable Micro QR code



Inverse



Anti-color



Aztec

Inverse



Anti-color



Han Xin

Anti-color



Inverse



Chapter 6 Troubleshooting

Q: There are some barcodes cannot be scanned.

Q: The barcode data is incorrect.

Q: Barcode can be read but not displayed.

Q: Aiming Light and Illumination are not bright.

Chapter 7 Scanner Settings

Barcode Setting Format

Prefix	Operand	Data

Version number—HYRS_RE



(default HID single scan mode)

BT, COM)

Serial Port

USB Virtual Keyboard

BT

General Serial Port

Data prefix

Disable	Custom Define

Data suffix

Disable	Custom Define

Aiming device (ON/OFF)

ON	OFF

Illumination light (ON/OFF)

OFF	Level 1	Level 2	Level 9	Level 10

Multi code quantity

OFF	2	3	6	7

Multi code sensitivity

Level 1

Timeout setting of the same barcode in non-single scan mode

Variable

Sensitivity


Normal	Fast	Ultra-Fast



Center aiming decode setting

Enable	Disable



■ Commands that support only barcodes



Barcode function settings

ITF cut the first few bits of data

Enable	Disable
	



Convert grouping character to space



Remove zero data at the beginning of barcode



Remove or reduce space



Skip the number of characters before barcode data



Skip the number of characters after barcode data



Barcode data case conversion



Insert characters into barcode data


Compound command parameters

Common suffix



Appendix I Barcode Enabling Settings


Appendix II Data code prefix and suffix



■ Prefix and Suffix



SP




!




"



#



\$



%



&




'



(



)



*



+



,




-




.




/



0



1




2



3



4



5



6



7




8



9



:



;



<



=



>




?




@

A



B



C



D



E



F



G



H



I



J



K



L



M



N




O



P



Q



R



S



T



U



V



W



X



Y



Z



[



\



]



^



-




'



a



b



c



d




e




f



g



h



i




j



k



l



m



n



o



p



q



r



s



t



u



v



w



x



y



z



{



|



}



~



DEL

Appendix III ASCII Code Table

00	0	NUL (Null char.)
01	1	SOH (Start of Header)
02	2	STX (Start of Text)
03	3	ETX (End of Text)
04	4	EOT (End of Transmission)
05		

21	33	! (Exclamation Mark)
22	34	" (Double Quote)
23	35	# (Number Sign)
24	36	\$ (Dollar Sign)
25	37	% (Percent)
26	38	& (Ampersand)
27	39	` (Single Quote)
28	40	((Right / Closing Parenthesis)
29	41) (Right / Closing Parenthesis)
2a	42	* (Asterisk)
2b	43	+ (Plus)
2c	44	, (Comma)
2d	45	- (Minus / Dash)
2e	46	. (Dot)
2f	47	/ (Forward Slash)
30	48	0
31	49	1
32	50	2
33	51	3
34	52	4
35	53	5
36	54	6
37	55	7
38	56	8
39	57	9
3a	58	: (Colon)
3b	59	; (Semi-colon)
3c	60	< (Less Than)
3d	61	= (Equal Sign)
3e	62	> (Greater Than)
3f	63	? (Question Mark)
40	64	@ (AT Symbol)
41	65	A
42	66	B
43	67	C
44	68	D

69	105	i
6a	106	j
6b	107	k
6c	108	l
6d	109	m
6e	110	n
6f	111	o
70	112	p
71	113	q
72	114	r
73	115	s
74	116	t
75	117	u
76	118	v
77	119	w
78	120	x
79	121	y
7a	122	z
7b	123	{ (Left/ Opening Brace)
7c	124	(Vertical Bar)
7d	125	} (Right/Closing Brace)
7e	126	~ (Tilde)
7f	127	DEL (Delete)